DVD HOME THEATRE SYSTEM HTS3152

User Manual	6
使用手册 （简体）	52
使用手册 （繁體）	98
Manual Pengguna	144

Thank you for choosing Philips.

Need help fast?

Read your Quick Use/Start Guide and/or User Manual first for quick tips that make using your Philips product more enjoyable. If you have read your instructions and still need assistance, you may access our online help at ***www.philips.com/welcome***

PHILIPS

1_hts3152_98_eng2.indd 1 2007-04-26 7:14:58 PM
Downloaded From TheatreSystem-Manual.com Manuals

部件名称 Name of the Parts	有毒有害物质或元素 Hazardous/Toxic Substance					
	铅 (Pb, Lead)	汞(Hg, Mercury)	镉(Cd, Cadmium)	六价铬 (Chromium 6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Housing 外壳	O	O	O	O	O	O
DVD loader DVD 光盒	X	O	O	O	O	O
Subwoofer 超重低音箱	X	O	O	O	O	O
Loudspeakers 喇叭单元	O	O	O	O	O	O
PWBs 电路板组件	X	O	O	O	O	O
Accessories (Remote control & cables) 附件（遥控器， 电源线，连接线）	X	O	O	O	O	O
Batteries in Remote Control (ZnC) 遥控器电池	X	O	O	O	O	O

○：表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363 – 2006 标准规定的限量要求以下。
O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363 – 2006.

×：表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363 – 2006 标准规定的限量要求。
X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363 - 2006.

环保使用期限 Environmental Protection Use Period

此标识指期限（十年），电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变，用户使用该电子信息产品不会对环境造成严重污染或对其人身、财产造成严重损害的期限。

This logo refers to the period (10 years) during which the toxic or hazardous substances or elements contained in electronic information products will not leak or mutate so that the use of these [substances or elements] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

电池标识 Battery labeling logo

环保使用期限 Environmental Protection Use Period

此标识指期限（五年），电池中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变，用户使用该电池产品不会对环境造成严重污染或对其人身、财产造成严重损害的期限。

This logo refers to the period (5 years) during which the toxic or hazardous substances or elements contained in the **battery** will not leak or mutate so that the use of these [substances or elements] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Downloaded From TheatreSystem-Manual.com Manuals

LASER	
Type	Semiconductor laser GaAlAs
Wave length	650 - 660 nm (DVD) 784 - 796 nm (CD)
Output Power	7 mW (DVD) 10 mW (VCD/CD)
Beam divergence	60 degrees

Due to the inconsistency of disc formats provided by various disc manufacturers, your DVD system/ player/recorder may require a playability enhancement or upgrade. As DVD technology advances, these enhancement will become common and will be easy to complete.
Go to www.philips.com/support for software upgrade.

'CONSUMERS SHOULD NOTE THAT NOT ALL HIGH DEFINITION TELEVISION SETS ARE FULLY COMPATIBLE WITH THIS PRODUCT AND MAY CAUSE ARTIFACTS TO BE DISPLAYED IN THE PICTURE. IN CASE OF 525 OR 625 PROGRESSIVE SCAN PICTURE PROBLEMS, IT IS RECOMMENDED THAT THE USER SWITCH THE CONNECTION TO THE 'STANDARD DEFINITION' OUTPUT. IF THERE ARE QUESTIONS REGARDING OUR TV SET COMPATIBILITY WITH THIS MODEL 525p AND 625p DVD PLAYER, PLEASE CONTACT OUR CUSTOMER SERVICE CENTER.'

CAUTION

Use of controls or adjustments or performance of procedures other than herein may result in hazardous radiation exposure or other unsafe operation.

ATTENTION!

For Customer Use:

Read carefully the information located at the bottom or rear of your DVD Home Theatre System and enter below the Serial No. Retain this information for future reference.

Model No. HTS3152

Serial No. _____

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reserve engineering or disassembly is prohibited.

Downloaded From TheatreSystem-Manual.com Manuals

Language Code

Abkhazian	6566
Afar	6565
Afrikaans	6570
Amharic	6577
Arabic	6582
Armenian	7289
Assamese	6583
Avestan	6569
Aymara	6589
Azerhaijani	6590
Bahasa Melayu	7783
Bashkir	6665
Belarusian	6669
Bengali	6678
Bihari	6672
Bislama	6673
Bokmål, Norwegian	7866
Bosanski	6683
Brezhoneg	6682
Bulgarian	6671
Burmese	7789
Castellano, Español	6983
Catalán	6765
Chamorro	6772
Chechen	6769
Chewa; Chichewa; Nyanja	7889
中文	9072
Chuang; Zhuang	9065
Church Slavic; Slavonic	6785
Chuvash	6786
Corsican	6779
Česky	6783
Dansk	6865
Deutsch	6869
Dzongkha	6890
English	6978
Esperanto	6979
Estonian	6984
Euskara	6985
Ελληνικά	6976
Faroese	7079
Français	7082
Frysk	7089
Fijian	7074
Gaelic; Scottish Gaelic	7168
Gallegan	7176
Georgian	7565
Gikuyu; Kikuyu	7573
Guarani	7178
Gujarati	7185
Hausa	7265
Herero	7290
Hindi	7273
Hiri Motu	7279
Hrwatski	6779
Ido	7379
Interlingua (International)	7365
Interlingue	7365
Inuktitut	7385
Inupiaq	7375
Irish	7165
Íslenska	7383
Italiano	7384
Ivrit	7269
Japanese	7465
Javanese	7486
Kalaallisut	7576
Kannada	7578
Kashmiri	7583
Kazakh	7575
Kernewek	7587
Khmer	7577
Kinyarwanda	8287
Kirghiz	7589
Komi	7586
Korean	7579
Kuanyama; Kwanyama	7574
Kurdish	7585
Lao	7679
Latina	7665
Latvian	7686
Letzeburgesch;	7666
Limburgan; Limburger	7673
Lingala	7678
Lithuanian	7684
Luxembourgish;	7666
Macedonian	7775
Malagasy	7771
Magyar	7285
Malayalam	7776
Maltese	7784
Manx	7186
Maori	7773
Marathi	7782
Marshallese	7772
Moldavian	7779
Mongolian	7778
Nauru	7865
Navaho; Navajo	7886
Ndebele, North	7868
Ndebele, South	7882
Ndonga	7871
Nederlands	7876
Nepali	7869
Norsk	7879
Northern Sami	8369
North Ndebele	7868
Norwegian Nynorsk;	7878
Occitan; Provencal	7967
Old Bulgarian; Old Slavonic	6785
Oriya	7982
Oromo	7977
Ossetian; Ossetic	7983
Pali	8073
Panjabi	8065
Persian	7065
Polski	8076
Português	8084
Pushto	8083
Russian	8285
Quechua	8185
Raeto-Romance	8277
Romanian	8279
Rundi	8278
Samoan	8377
Sango	8371
Sanskrit	8365
Sardinian	8367
Serbian	8382
Shona	8378
Shqip	8381
Sindhi	8368
Sinhalese	8373
Slovensky	8373
Slovenian	8376
Somali	8379
Sotho; Southern	8384
South Ndebele	7882
Sundanese	8385
Suomi	7073
Swahili	8387
Swati	8383
Svenska	8386
Tagalog	8476
Tahitian	8489
Tajik	8471
Tamil	8465
Tatar	8484
Telugu	8469
Thai	8472
Tibetan	6679
Tigrinya	8473
Tonga (Tonga Islands)	8479
Tsonga	8483
Tswana	8478
Türkçe	8482
Turkmen	8475
Twi	8487
Uighur	8571
Ukrainian	8575
Urdu	8582
Uzbek	8590
Vietnamese	8673
Volapuk	8679
Walloon	8765
Welsh	6789
Wolof	8779
Xhosa	8872
Yiddish	8973
Yoruba	8979
Zulu	9085

Downloaded From TheatreSystem-Manual.com Manuals

Index

English ---------- 6

中文(简体) ---------- 52

中文(繁體) ---------- 98

Bahasa Melayu---------- 144

English

中文(简体)

中文(繁體)

Bahasa Melayu

Manufactured under license from Dolby Laboratories, Dolby, Pro Logic and the double-D symbol are trademarks of Dolby Laboratories.

Manufactured under license from one or more of the following DTS, Inc. U.S. Pat. No's: 5,451,942; 5,956,674; 5,974,380; 5,978,762; 6,226,616; 6,487,535 and other U.S. and world-wide patents issued and pending. "DTS" and "DTS Digital Surround" are registered trademarks of DTS, Inc. Copyright 1996, 2002-2006, DTS, Inc. All Rights Reserved.

DivX Ultra Certified products: "DivX, DivX Ultra Certified, and associated logos are trademarks of DivX, Inc. and are used under license.

Windows Media and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries.

Downloaded From TheatreSystem-Manual.com Manuals

English

Table of contents

General

General Information 8
- Setup precautions 8
- Accessories supplied 8
- Cleaning discs 8
- About recycling 8

Product Overview

Main Unit 9

Remote Control 10-12
- Using the remote control 12

Connections

Basic Connections 13-16
- Step 1: Placing the speakers 13
- Step 2: Connecting to TV 14
  - Option 1: Using the Video socket 14
  - Option 2: Connecting to a Progressive Scan TV or component video input 14
- Step 3: Connecting speakers and subwoofer 15
- Step 4: Connecting the FM and AM/MW antennas 16
- Step 5: Connecting the power cord 16

Optional Connections 17
- Connecting audio from TV 17
- Connecting to cable box/satellite receiver and recorder/VCR 17

Basic Setup

Getting Started 18-22
- Finding the correct viewing channel 18
- Switching to different play source 18
- Setting language preferences 19
  - On-screen display (OSD) language 19
  - Audio, Subtitle and Menu language for DVD playback 19-20
- Setting the TV Display 20
- Setting up Progressive Scan feature 21
- Setting the speakers' channels 22

Disc Playback

Disc Operations 23-31
- Playable discs 23
- Playing a disc 23
- Basic playback controls 24
- Selecting various repeat/shuffle functions 24
- Programming disc tracks 25
- Other playback features for video discs (DVD/VCD/SVCD) 25-28
  - Using the Disc Menu 25
  - Viewing playback information 26
  - Zooming in/out 26
  - Changing subtitle language 26
  - Switching camera angles 26
  - Changing sound track language 27
  - Setting the delay times for audio playback 27
  - Playback Control (VCD only) 27
  - Preview function (VCD/SVCD only) 28

Downloaded From TheatreSystem-Manual.com Manuals

Table of contents

Playing a MP3/ WMA disc 29
Playing a JPEG image file (slide show) 30
Preview function 30
Zoom picture 30
Rotating/flipping the picture 30
Playing MP3/WMA music and JPEG pictures simultaneously 31
Playing a DivX disc 31

Playback other supported devices

Playback - USB Device 32
Playing from USB flash drive or USB memory card reader 32
Playback - Other Audio Player 33
Playing from other portable audio player 33
Playback - Karaoke 34
Playing a Karaoke disc 34

Setup Options

Setup Menu Options 35-40
Accessing the setup menu 35
General Setup Page 36
Audio Setup Page 37
Video Setup Page 38
Preference Page 39-40

Radio Tuning

Radio Operations 41-42
Tuning to radio stations 41
Changing tuning grid 41
Presetting radio stations 41-42
Using auto install 41
Using automatic preset 42
Using manual preset 42
Selecting a preset radio station 42
Deleting a preset radio station 42

Others

Sound and Volume Controls 43
Volume control 43
Selecting surround sound 43
Selecting digital sound effects 43
Other Features 44
Installing the latest software 44
Troubleshooting 45-47
Frequently Asked Questions (USB) 48
Specifications 49
Glossary 50-51

English

Downloaded From TheatreSystem-Manual.com Manuals

General Information

WARNING!
This unit does not contain any user-serviceable parts. Please leave all maintenance work to qualified personnel.

Setup precautions

Finding a suitable location
– Place this unit on a flat, hard and stable surface. Never place the unit on a carpet.
– Never place this unit on top of other equipment that might heat it up (e.g., receiver or amplifier).
– Never put anything under this unit (e.g., CDs, magazines).
– Install this unit near the AC outlet where the AC power plug can be easily reached.

Space for ventilation
– Place this unit in a location with adequate ventilation to prevent internal heat build up. Allow at least 10 cm (4") clearance from the rear and the top of this unit and 5cm (2") from the left and right to prevent overheating.

Avoid high temperature, moisture, water and dust
– This unit must not be exposed to dripping or splashing.
– Never place any object or items that can damage this unit (e.g., liquid filled objects, lighted candles).

Accessories supplied

– 1 subwoofer
– 2 front speakers
– 2 rear speakers
– 1 centre speaker
– 1 remote control with batteries
– 1 composite video cable (yellow)
– 1 FM wire antenna
– 1 AM/MW loop antenna
– 1 MP3 LINE-IN cable (for connecting portable audio player)
– 1 power cable
– Quick Start Guide

Cleaning discs

To clean a disc, use a micro fibre cleaning cloth and wipe the disc from the centre to the edge in a straight line.

CAUTION!
Never use solvents e.g. benzene, thinner, commercially available cleaners, or anti-static sprays intended for discs.

About recycling

These operating instructions have been printed on non-polluting paper. The electronic equipment contains a large number of materials that can be recycled. If you are disposing of an old machine, please take it to a recycling centre. Please observe the local regulations regarding disposal of packaging materials, exhausted batteries and old equipment.

Downloaded From TheatreSystem-Manual.com Manuals

Main Unit



① **STANDBY-ON**
– Turns on this unit or turns off to normal standby mode.

② **Disc Tray**

③ **OPEN/CLOSE ⏏**
– Opens/closes the disc tray.

④ **Display panel**

⑤ **PLAY/ PAUSE ▶II**
– DISC: starts/pauses playback.
– RADIO: starts auto radio installation for first time setup.

⑥ **SOURCE**
– Selects the relevant active source mode: DISC, FM, AM/MW, TV, AUX, MP3 LINE-IN.

⑦ **MIC LEVEL**
– Activates microphone level mode and use the volume control to set the microphone volume level.

⑧ **STOP ■**
– Exits an operation.
– DISC: stops playback.
– RADIO: press and hold this button to erase the current preset radio station.

⑨ **VOL**
– Adjusts the volume level.

⑩ **USB socket**
– Input for USB flash drive or USB memory card reader.

⑪ **MP3 LINE-IN socket**
– Phono input for connecting to the headphone out socket on your portable audio player.

⑫ **MIC socket**
– Input for microphone socket.

Downloaded From TheatreSystem-Manual.com Manuals

Remote Control



① ⏻
– Turns on this unit or turns off to normal standby mode.

② **Source buttons**
– **DISC/USB**: toggles between DISC or USB mode.
RADIO: toggles between FM and AM/ MW band.
TV: switches to TV mode. The sound from the TV will output through the connected speaker system.
AUX/DI: switches to the external device that is connected to the AUDIO IN-AUX socket.
MP3 LINE-IN: switches to audio device that is connected to the MP3 LINE-IN socket.

③ **OPEN/CLOSE ⏏**
– Opens/closes the disc tray.

④ **PROGRAM**
– DISC: starts programming.
– RADIO: press and hold this button to start automatic/ manual preset programming.

⑤ **ZOOM**
– Zoom in or out the picture on the TV.

⑥ **SETUP**
– Enters or exits the system setup menu.

⑦ **DISPLAY**
– Displays the current status or disc information.
– Selects a different viewing angle of a DVD movie (if available).

⑧ **PLAY/PAUSE ▶II**
– DISC: starts/pauses playback.
– RADIO: starts auto radio installation for first time setup.

⑨ **STOP ■**
– Exits an operation.
– DISC: stops playback.
– RADIO: press and hold this button to erase the current preset radio station.

⑩ **TV VOL +/–**
– Adjusts the volume of the TV (for Philips TVs or compatible brands only).

⑪ **AUDIO SYNC**
– Sets the audio output delay times if the video playback is slower than the audio output.

⑫ **KARAOKE**
– Enters microphone setting menu.

⑬ **VOCAL**
– Toggles between various audio mode.

Downloaded From TheatreSystem-Manual.com Manuals

English

⑭ **DISC MENU**
– For DVD, enters or exits disc contents menu.
– For VCD/SVCD, enters digest menu.

⑮ **OK**
– Confirms an entry or selection.

⑯ **▲▼◄ ►**
– DISC: selects movement direction in the menu.
– DISC: press left or right for fast forward and backward search.
– RADIO: press up or down to tune the radio frequency.
– RADIO: press left or right to start auto search.

⑰ **TITLE** ⮌
– For DVD, go back to the previous menu.
– For VCD version 2.0 only;
During playback, display the disc title menu or return to the main menu.

⑱ **PREV ⏮ / NEXT ⏭**
– DISC: skips to the previous or next title/ chapter/track.
– RADIO: selects a preset radio station.

⑲ **MUTE** 🔇
– Mutes or restores the volume.

⑳ **VOL +/–**
– Adjusts the volume level.

㉑ **SURROUND**
– Selects multi-channel surround or stereo mode.

㉒ **Numeric keypad 0-9**
– Enters a track/title number of the disc.
– Enters a number of a preset radio station.

㉓ **SOUND**
– Selects a predefined sound effect.



㉔ **SUBTITLE**
– Selects a DVD subtitle language.

㉕ **AUDIO**
– DISC: selects an audio language/channel.

Downloaded From TheatreSystem-Manual.com Manuals

Remote Control (continued)

Using the remote control



1. Open the battery compartment.
2. Insert two batteries type R03 or AAA, following the indications (+ −) inside the compartment.
3. Close the cover.
4. Point the remote control directly at the remote sensor (iR) on the front panel.
5. Select the source you wish to control by pressing the DISC/USB, RADIO, TV, AUX/DI or MP3 LINE-IN button on the remote control.
6. Then select the desired function (for example ⏮, ⏭).

CAUTION!
– Remove batteries if they are exhausted or if the remote control is not to be used for a long time.
– Never mix batteries (old and new or carbon and alkaline, etc).
– Batteries contain chemical substances, they should be disposed of properly.

Downloaded From TheatreSystem-Manual.com Manuals



Step 1: Placing the speakers

The Philips Home Theatre System is simple to install. However, proper system placement is critical to ensure an optimum sound experience.

1. Place the front left and right speakers at equal distances from the TV and at an angle of approximately 45 degrees from the listening position.
2. Place the centre speaker above the TV or the main unit such that the centre channel's sound is localised.
3. Place the rear speakers at normal listening ear level facing each other or hang on the wall.
4. Place the subwoofer at the corner of the room. Otherwise, keep it at least one metre away from the TV.

Helpful Hints:
– The placement diagram shown here is only a guideline that provides great system performance. You may find other placement choices that are more suitable for your room layout that provide the sound experience you enjoy.
– To avoid magnetic interference, never position the front speakers too close to your TV.
– The rear speakers are labelled as REAR LEFT or REAR RIGHT.
– The front speakers are labelled as FRONT LEFT or FRONT RIGHT.
– For speaker setting, see 'Getting Started - Setting the speakers' channel'.

Downloaded From TheatreSystem-Manual.com Manuals

Basic Connections (continued)



Step 2: Connecting to TV

This connection enables you to view the video playback from this unit. You only need to choose **one** of the options below to make the video connection.

– For a standard TV, follow option 1.

– For a progressive scan TV, follow option 2.

Helpful Hints:

– It is important to connect this unit directly to the TV in order to enjoy optimum video quality.

– To hear the TV channels through this unit, connect the AUDIO IN jacks to the corresponding AUDIO output jacks on the TV using an audio cable. Press TV on the remote control when watching the TV programs.

Option 1: Using the Video socket

- Connect a composite video cable (supplied) from the **CVBS** socket on the main unit to the video input socket (or labelled as A/V In, Video In, Composite or Baseband) on the TV.
  ➔ It provides good picture quality.

Option 2: Connecting to a Progressive Scan TV or component video input

The progressive scan video quality is only available when using Y Pb Pr connection and a progressive scan TV is required. It provides superior picture quality when watching DVD movies.

1. Connect the component video cables (red/ blue/green - not supplied) from the **Y Pb Pr** sockets on the main unit to the corresponding component video input sockets (or labelled as Y Pb/Cb Pr/Cr or YUV) on the TV.
2. If your TV accepts progressive signals, proceed to chapter 'Getting Started - Setting up Progressive Scan feature' for detailed progressive feature setup.

Downloaded From TheatreSystem-Manual.com Manuals



Step 3: Connecting speakers and subwoofer

- Connect all the speakers and subwoofer to the matching sockets at the rear of the main unit, Make sure that the colours of the plugs and sockets are matched.

Helpful Hint:
– To prevent unwanted noise, never place the speakers too close to the main unit, subwoofer, AC power adapter, TV or any other radiation sources.

Downloaded From TheatreSystem-Manual.com Manuals

Basic Connections (continued)





Step 4: Connecting the FM and AM/MW antennas

1 Connect the supplied AM/MW loop antenna to the **AM/MW** socket. Place the AM/MW loop antenna on a shelf, or attach it to a stand or wall.

2 Connect the supplied FM antenna to the **FM 75 Ω** socket. Extend the FM antenna and fix its ends to the wall.

For better FM stereo reception, connect an external FM antenna (not supplied).

Helpful Hints:
– Adjust the position of the antennas for optimal reception.
– Position the antennas as far away as possible from your TV, VCR or other radiation source to prevent any unwanted interference.

Step 5: Connecting the power cord

Notes:
– For power supply rating, refer to the rear or bottom of the main unit.
– Turning off to standby mode does not disconnect the unit from mains.

1 When completing all the connections, set the voltage selector to the local power line voltage.

2 Connect the AC power cord to the power outlet.
➔ The standby LED on the main unit lights up.

Helpful Hint:
– Before making or changing any connections, make sure that all the devices are disconnected from the power outlet.

Downloaded From TheatreSystem-Manual.com Manuals





Connecting audio from TV

When connecting the audio output from your TV to this Home Theatre System, you can have the sound of the TV output on all the speakers. It enables you to enjoy the multi-channel surround sound capabilities.

- Connect an audio cable (red/white - not supplied) from the **AUDIO IN-TV** sockets on the main unit to the AUDIO OUT sockets on the TV.

  To listen to the sound, press **TV** on the remote control as the sound source that you want to listen to.

Connecting to cable box/ satellite receiver and recorder/VCR

You can connect the audio output from an audio/video device (e.g. DVD Recorder, VCR, Cable/Satellite Box) to this Home Theatre System in order to enjoy the multi-channel surround sound capabilities.

- Connect an audio cable (red/white - not supplied) from the **AUDIO IN-AUX** sockets on the main unit to the AUDIO OUT sockets on the connected device.

  To listen to the sound, press **AUX/DI** as the sound source that you want to listen to.

Downloaded From TheatreSystem-Manual.com Manuals

Getting Started

Finding the correct viewing channel

1. Press **SOURCE** button on the main unit until 'DISC' appears on the display panel (or **DISC/USB** on the remote control).
2. Turn on the TV and switch it to the correct video-in channel.
   ➔ You may go to the lowest channel on your TV, then press the Channel Down button on your TVs remote control until you see the Video In channel.
   ➔ You may press ⊡ button repeatedly on your TV's remote control.
   ➔ Usually this channel is between the lowest and highest channels and may be called FRONT, A/V IN, VIDEO, etc..
   ➔ Refer to your TVs user manual on how to select the correct input on your TV.

Switching to different play source

- Press the **SOURCE** button on the front panel repeatedly to select:

  DISC → FM → AM/MW → TV → AUX → MP3 LINE-IN → DISC ....



Or

- Press **DISC/USB**, **RADIO**, **TV, AUX/DI** or **MP3 LINE-IN** on the remote control.
  ➔ Press **DISC/USB** to toggle between DISC and USB mode (if USB is detected).
  ➔ Press **RADIO** to toggle between FM and AM/MW band.
  ➔ If the audio input on this unit is connected to your TV, press **TV** to hear the TVs sound output through this unit.
  ➔ Press **AUX/DI** for switching to the external device that is connected to the AUDIO IN-AUX socket on this unit.
  ➔ Press **MP3 LINE-IN** for switching to the portable audio player that is connected to the MP3 LINE-IN socket on this unit.



Downloaded From TheatreSystem-Manual.com Manuals

Setting language preferences

The language options are different depending on your country or region. It may not correspond to the illustrations shown on the user manual.

On-screen display (OSD) language

The OSD (On-Screen Display) language for this unit remains as you have set it, regardless of the changes made to the DVD disc language.

1. In disc mode, press **SETUP** on the remote control.
   ➔ { **General Setup Page** } appears.
2. Press ▼ to highlight { **OSD Language** } in the menu and press ▶.



3. Use ▲▼ keys to select a language and press **OK** to confirm.

Audio, Subtitle and Menu language for DVD playback

You can select your preferred language settings for DVD playback. If the selected language is recorded on the DVD disc, this unit automatically plays the disc in that language. Otherwise, the disc's default language will be used instead.

1. Press ■ twice to stop playback (if any), then press **SETUP**.
2. Press ▶ repeatedly to select { **Preference Page** }.
3. Use ▲▼ keys to select one of the options below and press ▶.



{ **Audio** }
Select the preferred audio language for DVD playback.

{ **Subtitle** }
Select the preferred subtitle language for DVD playback.

{ **Disc Menu** }
Select the preferred disc menu language for DVD playback.

4. Use ▲▼ keys to select a language and press **OK** to confirm.

1_hts3152_98_eng2.indd 19 2007-04-26 7:15:02 PM
Downloaded From TheatreSystem-Manual.com Manuals

Getting Started (continued)

If the language you want is not available in the list, select { Others }. Use the **numeric keypad (0-9)** on the remote control to enter the 4-digit language code 'XXXX' (see page 4) and press **OK** to confirm.

5 Repeat steps 3 ~ 4 for other settings.

Helpful Hints:
– During DVD playback, you can switch the audio and subtitle languages by pressing the AUDIO and SUBTITLE buttons on the remote control. However, this does not change the default settings you have made here.
– For some DVDs, the subtitle/audio/menu language can only be changed via the DVD disc menu.

Setting the TV Display

Set the aspect ratio of this unit according to the TV type you have connected. The format you select must be available on the disc. If it is not, the setting for TV display will not affect the picture during playback.

1 In disc mode, press **SETUP** on the remote control.

2 Press ▶ repeatedly to select { **Video Setup Page** }.

3 Press ▼ to highlight { **TV Display** } in the menu and press ▶.



{ **4:3 Pan Scan** }
Select this if you have a conventional TV and want both sides of the picture to be trimmed or formatted to fit your TV.



{ **4:3 Letter Box** }
Select this if you have a conventional TV. In this case, a wide picture with black bands on the upper and lower portions of the TV will be displayed.

{ **16:9 Wide Screen** }
Select this if you have a wide-screen TV.

4 Select one of the options and press **OK** to confirm.

Downloaded From TheatreSystem-Manual.com Manuals

Setting up Progressive Scan feature

(for Progressive Scan TV only)
The progressive scan displays twice the number of frames per second than interlaced scanning (ordinary normal TV system). With nearly double the number of lines, progressive scan offers higher picture resolution and quality.

Before you start...
Ensure that you have connected this unit to a progressive scan TV using the Y Pb Pr connection (see 'Option 2: Connecting to a Progressive Scan TV or component video input').

1. Turn on the TV to the correct viewing channel for this unit.
   ➔ Make sure that the TVs progressive scan mode is turned off (or set to interlaced mode). Refer to your TVs user manual.
2. Turn on this unit and press **DISC/USB** on the remote control.
3. Press **SETUP** on the remote control.
4. Press ▶ repeatedly to select { **Video Setup Page** }.
5. Move to { **Progressive** } > { **On** } in the menu and press **OK** to confirm.



6. Read the notification message on the TV and confirm your action by selecting the OK in the menu and press **OK**.

   There will be no picture on your TV at this state until you have turned on the progressive scan mode on your TV.
7. Turn on your TV progressive scan mode, refer to your TVs user manual.
   ➔ A message appears on the TV.
8. Confirm your action by selecting the OK in the menu and press **OK**.
   ➔ The setup is now completed and you can start to enjoy the high quality picture.

If no picture is displayed

1. Press **OPEN/CLOSE** ⏏.
2. Press ◀ on the remote control.
3. Press **AUDIO** on the remote control.

Helpful Hints:
– If a blank/distorted screen appears, wait for 15 seconds for the auto recovery.
– There are some progressive scan TVs that are not fully compatible with this unit, resulting in an unnatural picture when playing back a DVD VIDEO disc in the progressive scan mode. In such a case, turn off the progressive scan feature on this unit and your TV

Downloaded From TheatreSystem-Manual.com Manuals

Getting Started (continued)

Setting the speakers' channels

You can adjust the delay times (centre and surround only) and volume level for individual speakers. These adjustments let you optimise the sound according to your surroundings and setup.

Before you start...
Stop the disc playback by pressing STOP button twice or remove the disc from the disc tray. Otherwise, the settings are not accessible.

1. In disc mode, press **SETUP** on the remote control.
2. Press ▶ repeatedly to select { **Audio Setup Page** }.
3. Press ▼ to highlight { **Speakers Volume** } and press ▶.



4. Use ◀▶ keys to set the volume level for each speaker (-6dB ~ +6dB) and press **OK** to confirm.
5. Use ▲▼ keys to highlight { **Speakers Delay** } and press ▶.



6. Use ◀▶ keys to set the delay times (0 ms ~ 15 ms) for centre and rear speakers that best suit your surround sound needs.
7. Press **OK** to confirm.

Helpful Hints:
– A 1ms increase/decrease of delay time is equivalent to 30 cm change in distance.
– Use the longer delay time settings when the rear speakers are closer to the listener than the front speakers.
– The test tone will be automatically generated to help you judge the sound level of each speaker.

Downloaded From TheatreSystem-Manual.com Manuals

Playable discs

Your DVD home theatre system plays:

- Digital Versatile Discs (DVDs)
- Video CDs (VCDs)
- Super Video CDs (SVCDs)
- Finalised DVD Recordable (DVD±R), DVD Rewritable (DVD±RW)
- Audio Compact Discs (CDs)
- MP3/ Windows Media™ Audio discs, picture (Kodak, JPEG) files on CD-R(W)
  - ISO 9660/UDF format
  - JPEG resolution support up to 3072 x 2048
  - Supported sampling frequencies: 32 kHz, 44.1 kHz, 48 kHz
  - Supported Bit-rates: 32~256 (kbps), variable bit rates (average 128 kbps)
- DivX files on CD-R(W)/DVD+R(W):
  - DivX 3/4/5/6, DivX Ultra

Region Codes for DVD discs

DVD discs and players are designed with regional restrictions. Before playing a disc, make sure the disc is for the same region as your player. The regional code for this unit is indicated at the rear or bottom panel.

Notes:

– If the inhibit icon (ø or X) appears on the TV when a button is pressed, it means the function is not available on the current disc or at the current time.

– Never put any objects other than discs on the disc tray. Doing so may cause the disc player to malfunction.

Playing a disc

1. Press **SOURCE** repeatedly until 'DISC' appears on the display panel (or press **DISC/USB** on the remote control).
2. Turn on the TV to the correct viewing channel for this unit.
   ➔ The blue DVD background screen appears on the TV.
3. Press **OPEN/CLOSE** ▲ to open the disc tray.
4. Load a disc and press **OPEN/CLOSE** ▲ to close the disc tray.
   ➔ Make sure the disc label is facing up. For double-sided discs, load the side which you want to play facing up.
5. Playback starts automatically.
   ➔ See the following pages for more playback options and features.

Helpful Hints:

– If you are having trouble playing a certain disc, remove the disc and try a different one. Improperly formatted discs cannot be played on this unit.

– Some discs cannot be played on this player due to the configuration and characteristics of the disc, or due to the condition of recording and authoring software that was used.

Downloaded From TheatreSystem-Manual.com Manuals

Disc Operations (continued)

Basic playback controls

Pausing playback

- During playback, press ▶II.
  ➔ While in pause mode, you can press ▶ to step forward one frame at each press.
  ➔ To resume playback, press ▶II again.

Selecting another track/chapter

- Press I◀ / ▶I or use the **numeric keypad 0-9** to key in a track/chapter number.
  ➔ If the repeat track mode is active, press I◀ again to replay the same track/ chapter.

Searching backward/forward

- Press ◀◀ / ▶▶ on the remote control.
  ➔ While searching, press ◀◀ / ▶▶ repeatedly to decrease/increase the search speed.
  ➔ To resume normal playback, press ▶II.

Stopping playback

- Press ■.

Helpful Hints:
– If the message 'To playback from the beginning, press PREV key' appears on the TV while you load in a disc, you can press I◀ to start playback from the beginning.
– This is a power-saving feature, this unit automatically switches to standby mode if you do not press any buttons within 15 minutes after a disc has stopped playing.

Selecting various repeat/ shuffle functions

The available of the repeat play options and shuffle play mode are vary depending on the disc type.

For DVD/SVCD/VCD only:

1. During playback, press **DISPLAY**.
   ➔ Playback information menu appears.
2. Press ▼ to highlight 'REPEAT' function in the menu.
3. Press ▶ to choose a repeat or shuffle play mode.

For other discs

- During playback, press **DISPLAY repeatedly to select different repeat options.**

DVD
→ RPT ONE (repeat chapter)
→ RPT TT (repeat title)
→ SHUFFLE (random play)
→ RPT SHF (repeat random play)
→ RPT OFF (exit repeat mode)

VCD/SVCD/CD
→ RPT ONE (repeat track)
→ RPT ALL (repeat disc)
→ SHUFFLE (random play)
→ RPT SHF (repeat random play)
→ RPT OFF (exit repeat mode)

MP3/ DivX/ Windows Media™ Audio
→ RPT ONE (repeat track)
→ RPT ALL/FLD (repeat folder)
→ SHUFFLE (random play)
→ RPT OFF (exit repeat mode)

Downloaded From TheatreSystem-Manual.com Manuals

English

Programming disc tracks

(not for Picture CD/MP3 discs)
You can play the contents of the disc in the order you want by programming the playing order of the tracks.

1. Press **PROGRAM** on the remote control.
   ➔ The programming menu appears.



2. Use the **numeric keypad (0-9)** to enter a valid track/chapter number.
3. Use ◀▶▲▼ keys to move the cursor to the next position.

- If there are more than ten total programme tracks, select { **Next** } on the screen and press **OK** (or press ▶| on the remote control) to access the next programming page.
- To remove the track/chapter from the programming menu, select the track/chapter and press **OK**.

4. Once complete, select { **Start** } on the screen and press **OK** to start playback.
   ➔ Playback starts from the selected track under the programmed sequence.
5. To exit the programme menu, select { **Exit** } in the menu and press **OK**.

Other playback features for video discs (DVD/VCD/SVCD)



Note:
The operating features described here might not be possible for certain discs. Always refer to the instructions supplied with the discs.

Using the Disc Menu

Depending on the disc format, a menu may appear on the TV screen once you load the disc.

To select a playback feature or item

- Use ◀▶▲▼ keys or **numeric keypad 0-9** on the remote control, then press **OK** to start playback.

To access or remove the menu

- Press **DISC MENU** on the remote control.

Downloaded From TheatreSystem-Manual.com Manuals

Disc Operations (continued)

Viewing playback information

This unit can display the disc playback information (for example, title or chapter number, elapsed playing time, audio/ subtitle language) and a number of operations can be done without interrupting disc playback.

1. During playback, press **DISPLAY**.
   ➔ A list of available disc information appears on the TV.

DVD



VCD/SVCD



2. Use ▲▼ keys to view the information and press **OK** to access.
3. Use the **numeric keypad 0-9** to input the number/time or use ▲▼ keys to make the selection.
4. Press **OK** to confirm.
   ➔ Playback changes according to the chosen time or to the selected title/ chapter/track.

Zooming in/out

This option allows you to zoom in or out the picture on the TV and to pan through the picture.

1. During playback, press **ZOOM** repeatedly to select a different zoom factor.
   ➔ Playback continues.
2. Use ◀▶▲▼ keys to pan through the zoomed image.
3. Press **ZOOM** repeatedly to return to the original size.

Changing subtitle language

This operation works only on DVDs with multiple subtitle languages. You can change the language you want while playing a DVD.

- Press **SUBTITLE** repeatedly to select different subtitle languages.

Switching camera angles

This option is only available on DVDs that contain sequences recorded from different camera angles. This allows you to view the picture from different angles.

1. During playback, press **DISPLAY**.
   ➔ Playback information menu appears.
2. Press ▼ to highlight 'ANGLE' function in the menu.
3. If different camera angles choices are available, press ▶ and numeric keys to select.

Downloaded From TheatreSystem-Manual.com Manuals

Changing sound track language

This operation works only on DVDs with multiple sound track languages, or VCDs with multiple audio channels.

- Press **AUDIO** repeatedly to select the available audio languages.

For VCD – changing the audio channel

- Press **AUDIO** repeatedly to select the available audio channels provided by the disc (STEREO, MONO LEFT, MONO RIGHT or MIX MONO).

Setting the delay times for audio playback

This feature allows you to adjust the audio delay times if the video playback is slower than the audio output streams, hence resulting in 'Lip-sync'. The only way to correct 'Lip-sync' error caused by delayed video is to delay audio by an equal amount.

1. Press **AUDIO SYNC**.
2. Within five seconds, use the **VOL** + − to set the audio output delay times (0 ~ 200 ms).
   ➔ If the volume control is not used within five seconds, it resumes its normal volume control function.

Helpful Hint:
– Set your preferred default AUDIO SYNC setting in the setup menu, see 'Setup Menu Options - { Audio Setup Page }'.

Playback Control (VCD only)

Playback Control (PBC) playback allows you to play Video CDs interactively, following the menu on the display. The PBC feature on this unit is turned on by default.

For VCDs with Playback Control (PBC) feature (version 2.0 only)

- During playback, press **TITLE** ⮌ to return to the disc title menu or main menu.

Helpful Hint:
– Set your preferred default PBC setting in the setup menu, see 'Setup Menu Options - { Preference Page }'.

Downloaded From TheatreSystem-Manual.com Manuals

Disc Operations (continued)

Preview function (VCD/SVCD only)

This function allows you to preview the contents of a VCD/SVCD.

1 Press **DISC MENU**.



2 Use ▲▼ keys to select one of the following options and press **OK**.

{ **Track Digest** }
View six different tracks on one screen each time. It allows you to have a quick glance at all the tracks on the disc.

{ **Disc Interval** }
View the whole disc in six thumbnail pictures. It divides a disc into six portions at regular intervals and displays them on one screen.

{ **Track Interval** }
View the content of a single track in six thumbnail pictures. It divides a single track into six portions at regular intervals and displays them on one screen.
This option is only available during playback mode.



- To go to the previous or next page, press ⏮ / ⏭.
- To return to the main menu, select { **Menu** } on the screen and press **OK**.
- Press **OK** on the selected thumbnail picture to start playback from there.

3 To exit the preview menu, select { **Exit** } on the screen and press **OK**.

Downloaded From TheatreSystem-Manual.com Manuals

Playing a MP3/WMA disc

This unit can playback most of the MP3 and Windows Media™ Audio files recorded on a recordable disc or commercial CD.

Before you start ...
Turn on your TV to the correct Video In channel. See 'Finding the correct viewing channel' for details.

1 Insert a MP3/WMA disc.
➔ The disc reading time may exceed 30 seconds due to the complexity of the directory/file configuration.
➔ The disc menu appears on the TV.



2 If the disc main menu contains various folders, use ▲▼ keys to select a desired folder and press **OK** to open the folder.

3 Use ▲▼ keys to select a track/file and press **OK** to start playback.
➔ Playback starts from the selected file and continue through to the end of the folder.

During playback;

- Press ⏮ / ⏭ to playback another track/ file in the current folder.
- Press ◀◀ / ▶▶ to fast reverse/forward search for a music track.
- To select another folder from the current disc, press ▲ repeatedly to highlight 'Previous' folder and press **OK** to return to the root menu.
- Press **DISPLAY** repeatedly to access various play modes.

4 To stop playback, press ■.

Helpful Hints:
– To skip the folders menu when you load a MP3/JPEG disc, set the MP3/JPEG NAV setting in the Preference Setup Page to { Without Menu }.
– Only the first session of a multi-session CD will be played back.
– It is normal to experience an occasional 'skip' while listening to your MP3/WMA disc due to poor clarity of digital contents during internet downloading.
– If any special characters are present in the MP3/WMA track name (ID3) or album name, it might not be displayed correctly on the screen because this unit does not support the characters.

Downloaded From TheatreSystem-Manual.com Manuals

Disc Operations (continued)

Playing a JPEG image file (slide show)

Before you start ...
Turn on your TV to the correct Video In channel. See 'Finding the correct viewing channel' for details.

- Insert a JPEG photo CD (Kodak Picture CD, JPEG).
  ➔ For a Kodak disc, the slide show begins automatically.
  ➔ For a JPEG disc, the picture menu appears on the TV. Press ▶II to start the slide-show playback.

Helpful Hint:
– It may require longer time for this unit to display the disc content on the TV due to the large number of songs/pictures compiled into one disc.

Supported file format:
– The file extension has to be '*.JPG' and not '*.JPEG'.
– This unit can only display digital camera pictures according to the JPEG-EXIF format, typically used by almost all digital cameras. It cannot display Motion JPEG, progressive JPEG and other JPEG formats, or pictures in formats other than JPEG, or sound clips associated with pictures.

Preview function

1. During playback, press ■.
   ➔ 12 thumbnail pictures will be displayed on the TV.



2. Press I◀ / ▶I to display the other pictures on the previous/next page.
3. Use ◀▶▲▼ keys to select one of the pictures and press **OK** to start playback.
4. Press **DISC MENU** to return to Picture CD menu.

Zoom picture

1. During playback, press **ZOOM** repeatedly to select a different zoom factor.
2. Use ◀▶▲▼ keys to pan through the zoomed image.

Rotating/flipping the picture

- During playback, use ◀▶▲▼ keys to rotate/flip the picture on the TV.

  ▲ : flip the picture vertically
  ▼ : flip the picture horizontally
  ◀ : rotate the picture anti-clockwise
  ▶ : rotate the picture clockwise

Downloaded From TheatreSystem-Manual.com Manuals

Playing MP3/WMA music and JPEG pictures simultaneously

You can create a musical slide show if the disc contains both the MP3/WMA music and JPEG picture files.

1. Insert a MP3/WMA disc that contains music and pictures.
2. Select a track in the menu and press **OK** to start playback.
3. During music playback, use ▲▼ keys to select a picture file from the disc menu and press **OK**.
   ➔ The picture files will be played back through to the end of the folder.
   ➔ The music keeps playing back and will be repeated if reaches the end of the selected album, playlist or track.
4. To stop simultaneous playback, press **DISC MENU** followed by ■.

Playing a DivX disc

This unit supports the playback of DivX movies which you can copy from your computer onto a recordable disc. See 'Setup Menu Options - { General Setup Page - DivX(R) VOD code }' for details.

1. Insert a DivX disc.
2. Use ◀▶▲▼ keys to navigate to the title you want to play.
3. Press **OK** to start playback.

During playback;

- If the DivX disc has multilingual subtitles, you can press **SUBTITLE** on the remote control to change the subtitle language.
- If the DivX title has different audio tracks, you can press **AUDIO** on the remote control to change the audio stream.
- Use ◀◀ / ▶▶ keys on the remote control to perform fast reverse/forward search.
- Press **DISPLAY** repeatedly until the Time Search menu appears, key in the time where playback should start.
  ➔ Playback skips to the time entered.

Helpful Hints:
– Subtitle files with the following file name extensions (.srt, .smi, .sub, .ssa, .ass) are supported but do not appear on the file navigation menu.
– The subtitle file name has to be the same as the file name of the movie.
– The subtitle can only be displayed up to an average of 45 characters.

1_hts3152_98_eng2.indd 31 2007-04-26 7:15:02 PM
Downloaded From TheatreSystem-Manual.com Manuals

Playback - USB Device

Playing from USB flash drive or USB memory card reader

You can play or view the data files (JPEG, MP3, Windows Media™ Audio or DivX) in the USB flash drive or USB memory card reader. However, editing or copying the data file is not possible.



1. Connect the USB flash drive / USB memory card reader directly to the **USB** socket on this unit.
2. A message appears on the TV for 5 (five) seconds when the device is detected.

3. Press **DISC/USB** on the remote control to access the data in the drive.
   ➔ When using multiple drives on a single card reader, only one of the connected cards can be accessed.
   ➔ The device numbers may vary from different card readers.
4. Select the file to play and press ►II.

- For more playback information, see 'Playing a MP3/WMA disc,' 'Playing a JPEG image file (slideshow)' or 'Playing a DivX disc' for details.
- During playback, you can press **DISC/USB** to return to the disc mode.

5. Before removing the USB device, press ■ to stop playback or press **DISC/USB** to switch to disc mode.

Helpful Hints:
– The USB socket does not support the connection of other USB devices except to a USB flash drive / USB memory card reader.
– When the USB device does not fit into the USB socket, a USB extension cable is required.
– You can only read and playback the content from the USB device.
– Copy-protected contents are not playable.

Downloaded From TheatreSystem-Manual.com Manuals

Playing from other portable audio player

Connect your portable audio player to this unit to get the best immersion sound experience through the speaker system. However, controlling of playback is only possible on the portable audio player.



1. Use the supplied MP3 LINE-IN cable to connect between the 'headphone' output socket on your portable audio player and the **MP3 LINE-IN** socket on this unit.
2. Press **MP3 LINE-IN** on the remote control.
3. Start playback on your portable audio player.
   ➔ The music will be heard through the speakers.
4. To stop playback, press the STOP button on the portable audio player.

Helpful Hint:
– If you change the input source by pressing any of the source buttons (e.g. DISC/USB, RADIO), press the STOP button on the portable audio player to stop its playback.

Downloaded From TheatreSystem-Manual.com Manuals

Playback - Karaoke

Playing a Karaoke disc

1 Connect a microphone (not supplied) to the **MIC** socket at the right side panel of the main unit (as shown below).





2 Insert a karaoke disc.

- If the disc menu appears, use ▲▼ keys to make your selection and press **OK** to start playback.

3 To turn off the vocal or change the sound channel of a karaoke disc, press **VOCAL** repeatedly to toggle between various audio modes.

4 Start enjoying the karaoke.

- While singing, you can press **MIC LEVEL** on the main unit followed by adjusting the volume control to set the microphone volume level.

Microphone setting

1 Press **KARAOKE** to access 'Microphone Setup' page.



2 In 'Microphone Setup' page, use ▲▼ keys to select the option for microphone settings and press **OK** to confirm.

{ Mic } - On - Off	To turn on or off the karaoke microphone.
{ Mic Volume }	Set the microphone volume level (0 ~ 20). Default setting is 10.
{ Echo Level }	Set the Echo Level (0 ~ 20). Default setting is 10.
{ Key }	Set the pitch level (-10~ +10) that matching your voice. **Note:** Select '-10' for lowest possible tone and '+10' for highest tone. To return to original tone, select '00'.
{ Score } - Off - Easy - Normal - Hard	Select the level of scoring option. **Note:** Select { Off } to turn off the karaoke scoring option.

Downloaded From TheatreSystem-Manual.com Manuals

Accessing the setup menu

This system setup is carried out via the TV, enabling you to customise this unit to suit your particular requirements.



1. In disc mode, press **SETUP** on the remote control.
   ➔ The setup menu appears.
2. Use ◀ ▶ keys to select one of the setup menu options and press **OK**.



- If you are not able to access the { Preference Page }, press **SETUP** to exit the menu. Then, press **STOP** ■ twice before you press the **SETUP** again.

3. Use ▲▼ keys to select a setup option and press ▶ to access.
4. Select the setting you wish to change and press **OK** to confirm and go back to the previously selected item.
   ➔ Instructions and explanations of the options are provided in the following pages.
   ➔ If the option in the menu is greyed out, that means the setting is not available or cannot be changed in the current state.
5. To exit, press **SETUP**.



see page 36



see page 37



see page 38



see pages 39~40

Downloaded From TheatreSystem-Manual.com Manuals

Setup Menu Options (continued)

General Setup Page (underlined options are the factory default settings)

Disc Lock

Not all discs are rated or coded by the disc maker. You can prevent play of specific discs with the disc lock function. Up to 40 discs can be locked.

{ **Lock** } – To block the playback of the current disc. Subsequent access to a locked disc requires a six-digit password. The default password is '136900' (see 'Preference Setup Page - { Password }).

{ **Unlock** } – All discs can be played.

Display Dim

Select the brightness of this unit's display panel.

{ **100%** } – Full brightness.

{ **70%** } – Medium brightness.

{ **40%** } – Dimmest display. This switches off all LEDs and icons on the front display panel of this unit.

Program

Access the track programming menu. See 'Programming disc tracks' for details.

OSD Language

Select the menu language for this unit's on-screen display.

Screen Saver

The screen saver prevents damage to the TV screen by avoiding exposure to a static image for too long.

{ **On** } – Switch to TV screen saver mode when playback has been stopped or paused for more than 5 minutes.

{ **Off** } – Turn off the screen saver function.

Sleep

The sleep timer enables the unit to switch to standby mode automatically after the selected preset time.

{ **15/30/45/60 mins** } – Select the preset minutes for switching the unit to standby mode automatically.

{ **Off** } – Turn off the sleep mode function.

DivX(R) VOD Code

Philips provides you with the DivX® VOD (Video On Demand) registration code that allows you to rent or purchase videos from DivX® VOD service at www.divx.com/vod. All the downloaded videos from DivX® VOD can only be played back on this unit.

Press ▶ to see the registration code and press **OK** to exit.

Downloaded From TheatreSystem-Manual.com Manuals

Audio Setup Page (underlined options are the factory default settings)

Speakers Volume

Access the speaker's level setup menu. Use ◀ ▶ keys to adjust the volume level for each connected speaker between -6dB to +6dB. See 'Getting Started - Setting the speakers' channels'.

Speakers Delay

Access the speaker's distance setup menu. Use ◀ ▶ keys to set the delay times for the centre and rear speakers based on the listening position and distance. See 'Getting Started - Setting the speakers' channels'.

Note: 1 ms increase/decrease of delay time is equivalent to one (1) foot change in distance. Use the longer delay time settings when the rear speakers are closer to the listener than the front speakers.

CD Upsampling

This feature enables you to convert the music CD to a higher sampling rate using sophisticated digital signal processing for better sound quality.

{ **Off** } – Turn off CD-upsampling.

{ **88.2 kHz (X2)** } – To convert the sampling rate of the CDs twice as high as the original rate.

Notes:

– If you have activated the CD upsampling feature, the audio output automatically switches to stereo mode.

– If you press the SURROUND button on the remote control to select multi-channel mode, it turns off the CD upsampling feature.

Audio Sync

This feature allows you to adjust the audio delay times if the video playback is slower than the audio output streams.

Use ◀ ▶ keys to set the delay times for the audio output between 0~200ms.

Downloaded From TheatreSystem-Manual.com Manuals

Setup Menu Options (continued)

Video Setup Page (underlined options are the factory default settings)

TV Type

Select the colour system that matches the connected TV. It enables playback of a different type of disc (PAL or NTSC disc) on this unit.

{ **PAL** } – For PAL-system TV.
{ **NTSC** } – For NTSC-system TV.
{ **Multi** } – For TV that is compatible with both PAL and NTSC.

TV Display

The picture shape can be adjusted to fit your TV.

{ **4:3 Pan Scan** } – For a full-height picture with the sides trimmed.

{ **4:3 Letter Box** } – For a 'wide-screen' display with black bars on the top and bottom.

{ **16:9 Wide Screen** } – For wide-screen TV (frame ratio 16:9).

Progressive

Before enabling the progressive scan feature, you must ensure that your TV can accept progressive signals (a progressive scan TV is required) and that you have connected this unit to your TV using the Y Pb Pr. See 'Getting Started - Setting up progressive scan feature' for details.

{ **On** } – Turn on progressive scan mode. Read the instructions on the TV and confirm your action by pressing **OK** on the remote control.
{ **Off** } – Turn off the progressive scan mode.

Picture Setting

This unit provides three predefined sets of picture colour settings and one personal setting which you can define yourself.

{ **Standard** } – Original colour setting.
{ **Bright** } – Vibrant colour setting.
{ **Soft** } – Warm colour setting.
{ **Personal** } – Select this to personalise the picture colour setting. Use ◀ ▶ keys to adjust to the setting that best suits your personal preference and press **OK** to confirm. For an average setting, select { 0 }.



Downloaded From TheatreSystem-Manual.com Manuals

Preference Page (underlined options are the factory default settings)

Audio

Select the preferred audio language for DVDs with multiple sound tracks.

Subtitle

Select the preferred subtitle language for DVD playback.

Disc Menu

Select the preferred disc menu language for DVD playback.

Note: If the selected audio/subtitle/disc menu language is not available on the DVD, the disc's default language will be used instead.

Parental

This is to prohibit viewing of discs that had exceeded the limits you set. It works only on the DVDs with parental level assigned to the complete disc or to certain scenes on the disc.

1) Use ▲▼ keys to select a rating level from 1 to 8 and press **OK**.
2) Use the **numeric keypad 0-9** on the remote control to enter your six-digit password.

Notes:

– The ratings are country-dependent ('**1**' is considered material that is least offensive and '**8**' is most offensive). To disable parental controls and allow all discs to play, select '**8**'.
– Some DVDs are not encoded with a rating though the movie rating may be printed on the disc cover. The rating level feature does not prohibit playback of such discs. VCD, SVCD and CD have no level indication, so parental control has no effect on these type of discs.
– DVDs that are rated higher than the level you selected will not be played unless you enter the same six-digit password.

Surround

Set the preferred surround setting when the unit is powered up.

{ **On** } – Turn on to multi-channel surround mode.
{ **Last Setting** } – Turn on to the last surround setting.

PBC

Play Back Control feature is applicable for VCD/SVCD only. It allows you to play Video CDs (2.0) interactively, following the menu on the display.

{ **On** } – The index menu (if available) appears on the TV when you load a VCD/SVCD.
{ **Off** } – The VCD/SVCD skips the index menu and playback directly from the beginning.

Downloaded From TheatreSystem-Manual.com Manuals

Setup Menu Options (continued)

Preference Page (underlined options are the factory default settings)

MP3/JPEG Nav

MP3/JPEG Navigator can only be set if the disc is recorded with a menu. It allows you to select different display menus for easy navigation.

{ **Without Menu** } – Display all the files contained in the MP3/ Picture disc.

{ **With Menu** } – Display the folder menu of the MP3/Picture disc.

Note: This unit can only display 650 files/folder in the directory.

Password

The password is used for the Disc Lock and Parental. The default password is '136900'. To change the password:

1) Press **OK** to access the change password menu.



2) Use the **numeric keypad 0-9** on the remote control to enter your existing six-digit password at { Old Password }.

Note: When doing this for the first time or if you forget your existing password, key in '136900'.

3) Enter the new six-digit password at { New Password }.
4) Enter the new six-digit password again at { Confirm PWD }.
5) Press **OK** to confirm and exit the menu.

DivX Subtitle

Select the font type that supports the recorded DivX subtitle.

{ **Central Europe** } – Display Central Europe fonts.
{ **Cyrillic** } – Display Cyrillic fonts.
{ **Greek** } – Display Greek subtitle fonts.
{ **Standard** } – Display a standard list of Roman subtitle fonts provided by this unit.
{ **Hebrew** } – Display Hebrew subtitle fonts.
{ **Chinese (Simp)** } – Display Simplified Chinese fonts.
{ **Korean** } – Display Korean fonts.

Default

This feature enables you to reset all the setup menu options and your personal settings to the factory defaults, except your password for the Disc Lock and Parental.

Press **OK** to confirm the default reset.

Downloaded From TheatreSystem-Manual.com Manuals

Before you start ...
Make sure the FM and AM/MW antennas are connected.

Tuning to radio stations

1. Press **SOURCE** repeatedly until 'FM' appears on the display panel (or press **RADIO** on the remote control).
2. Press ◀ / ▶ on the remote control to start tuning.
   ➔ The frequency indication starts to change until a radio station with sufficient signal strength is found.
3. Repeat step 2 if necessary until you find the desired radio station
4. To fine-tune the reception of a weak station, press ▲ / ▼ briefly and repeatedly until an optimal reception is found.

Changing tuning grid

(only applicable for certain regions)
In some countries, the frequency step between adjacent channels in the (AM/ MW)/ FM band is 9 kHz/ 50 kHz (10 kHz/ 100 kHz in some areas).

Note:
Changing the tuning grid erases all previously stored preset radio stations.

1. Press **SOURCE** repeatedly until 'FM' or 'AM/MW' appears
2. Press ■.
3. Press and hold ▶II until 'GRID 9' or 'GRID 10' appears.

Presetting radio stations

You can store up to 40 FM and 20 AM/MW preset radio stations in the memory. There are three different ways to program the radio stations:
– Using auto install (for first time setup only)
– Using automatic preset
– Using manual preset

Helpful Hints:
– This unit exits presetting mode if no button is pressed within 20 seconds.
– If no stereo signal is detected or less than 5 (five) stations are detected during radio installation, 'CHECK ANTENNA' appears.

Using auto install

When you access the 'RADIO' mode for the very first time, you will be prompted to install the radio stations. With this feature, you can install all the available radio station automatically with one touch of button.



1. Press **RADIO**.
   ➔ 'AUTO INSTALL ... PRESS PLAY' appears.

Downloaded From TheatreSystem-Manual.com Manuals

Radio Operations (continued)

2 Press ▶II.
➔ This unit starts searching from the FM band followed by the AM/MW band.
➔ All the available radio stations with strong signal will be stored automatically.
➔ Once complete, the first tuned radio station will be played back.

Using automatic preset

Use automatic presetting to store or reinstall all the preset radio stations.



1 Press **RADIO** to select 'FM' or 'AM/MW' band.

2 Press and hold **PROGRAM** until 'START ...' appears on the display panel.
➔ All previously stored radio stations will be replaced.

Using manual preset

Use manual presetting to store your favourite radio stations.

1 Tune to your desired radio station (see 'Tuning to radio stations').

2 Press **PROGRAM**.

3 Use I◀ / ▶I keys to select a preset number that you want to store the current radio station.

4 Press **PROGRAM** to store.

Selecting a preset radio station

1 Press **RADIO** to select 'FM' or 'AM/MW' band.

2 Use I◀ / ▶I keys to select a preset radio stations (or use the numeric keypad on the remote control).
➔ The preset number and radio frequency appear on the display panel.

Deleting a preset radio station

1 In radio mode, use I◀ / ▶I keys to select a preset radio station.

2 Press and hold ■ until 'FM/AM/MW X DELETED' appears.
➔ 'X' is the preset number.
➔ The radio station continues to play but has been deleted from the preset list.
➔ The rest of the preset radio stations remain unchanged.

Downloaded From TheatreSystem-Manual.com Manuals



Volume control

- Press **VOL** + / – to increase or decrease the volume level.
  ➔ 'VOL MIN' is the minimum volume level and 'VOL MAX' is the maximum volume level.

To turn off the volume temporarily

- Press **MUTE** .
  ➔ Playback continues without sound and 'MUTE' appears.
  ➔ To restore the volume, press **MUTE** again, or increase the volume level.

Selecting surround sound

- Press **SURROUND** to select between Multi-Channel or Stereo sound.
  ➔ The availability of the various surround sound modes depends on the sound available on the disc.
  ➔ The available output modes for Multi-channel include: Dolby Digital, DTS (Digital Theatre Systems) Surround and Dolby Pro Logic II.
  ➔ Stereo broadcasts or recordings will produce some surround channel effects when played in a surround mode.

Selecting digital sound effects

Select a preset digital sound effect that matches your disc's content or that optimises the sound of the musical style you are playing.

- Press **SOUND** to select the available sound effect.

Movies	Music	Description
CONCERT	CLASSIC	Flat and pure sound mode. Ideal for listening to classical music and watching live concert DVDs.
DRAMA	JAZZ	Clear mid and high range. Recreates the atmosphere of a live club with the artist just in front of you. Good for Jazz music and watching dramas.
ACTION	ROCK	Enhanced low and high range for great sounding movie effects and atmosphere. Great for action movies and rock/pop music.
MTV	RnB	Enhanced low and mid range for groovy and punchy sounds. Suitable for R&B, Hip Hop and MTV videos.
GAMING	PARTY	Slightly enhanced low range and strong mid range ideal for party music and video gaming.
CARTOON	LOUNGE	Moderate sound mode suitable for lounge music and watching cartoons.
SPORTS	SPORTS	Moderate mid range and surround effects for clear vocals and the atmosphere of a live sports venue.
NEWS	NEWS	Enhanced mid range for clear vocals/speech.
NIGHT	NIGHT	Dynamically controlled sound mode suitable for watching movies at night or for non-intrusive background music.

Downloaded From TheatreSystem-Manual.com Manuals

Other Features

Installing the latest software

Periodically Philips will issue software upgrades to enhance the user experience.

1. Get the software version of this unit by pressing **OPEN/CLOSE** ▲ to open the disc compartment
2. Press **DISPLAY** on the remote control.
   ➔ Write down the information for your current software version.
3. Visit the Philips website 'www.philips.com/support' to check the availability of the latest software upgrade and download the software to a CD-R.
4. Insert the CD-R to the disc tray.
   ➔ The software starts to install on this unit automatically.

   Note:
   Never unplug or turn off this unit during the upgrade.
5. When the disc compartment opens, remove the CD-R.
   ➔ The software upgrading is in process.
6. Once complete, it turns off to standby mode automatically.

Downloaded From TheatreSystem-Manual.com Manuals

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Never open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to solve a problem by following these instructions, consult your dealer or Philips for help.

Problem (General)	Solution
No power.	– Press STANDBY-ON on the unit to turn on the power. – Make sure the mains cord is properly connected and the AC outlet has power.
No picture.	– Refer to your TVs manual for correct Video In channel selection. Change the TV channel until you see the DVD screen. – Press DISC/USB to select disc mode. – If this happens when you turn on the progressive scan feature, wait for 15 seconds for the auto recovery or switch back to the default mode as below: 1) Press **OPEN/CLOSE** ⏏. 2) Press ◀ on the remote control. 3) Press **AUDIO** on the remote control.
Completely distorted picture or black/white picture.	– Check the video connection. – Sometimes a small amount of picture distortion may appear. This is not a malfunction. – The disc is dirty. Clean the disc.
No sound or distorted sound.	– Adjust the volume. – Check the speaker connections and settings. – Make sure that the audio cables are connected and press SOURCE to select the correct input source (for example, TV or AUX/DI) to choose the device that you want to hear through this unit.
No surround sound effect from the speakers.	– Press SURROUND to select a correct surround sound setting. – Make sure that the source you are playing is recorded or broadcast in surround sound (DTS, Dolby Digital, etc).
The remote control does not function properly.	– Select the source you want to play (for example, DISC/USB or RADIO) before pressing the function button (▶, ⏮ / ⏭). – Reduce the distance between the remote control and this unit. – Batteries are weak, replace the batteries. – Point the remote control directly toward the IR sensor.

Downloaded From TheatreSystem-Manual.com Manuals

Troubleshooting (continued)

Problem (Playback)	Solution
The unit does not start playback.	– Insert a readable disc with the playback side facing down. The DVD+R/CD-R must be Finalised. – Make sure the disc is not scratched or warped. – Press SETUP to turn off the system setup menu screen. – You may need to enter the password in order to unlock the disc for playback. – Moisture may have condensed inside this unit. Remove the disc and leave this unit turned on for about an hour.
The aspect ratio of the screen cannot be changed even though you have set the TV display.	– The aspect ratio is fixed on the DVD disc. – Depending on the TV, it may not be possible to change the aspect ratio.
Cannot activate some features e.g. Angles, Subtitles, or multi-language Audio.	– The features may not be available on the DVD. – Changing the language for the sound or subtitle is prohibited on this DVD.
Not able to select some items in the setup/system menu.	– Press STOP button twice before selecting the system setup menu. – Depending on the disc availability, some menu items cannot be selected.
Unable to play DivX movies.	– Ensure that the DivX file is encoded according to the 'Home Theatre Profile' with the DivX encoder. – Check that the DivX movie downloaded is a complete file.
Radio reception is poor.	– If the signal is too weak, adjust the antenna or connect an external antenna for better reception. – Increase the distance between this unit and your TV or VCR. – Tune in to the correct frequency. – Place the antenna further away from any equipment that may be causing the interference.
The unit does not work.	– Disconnect the power cord from the power outlet for a few minutes. Reconnect the power cord and try to operate again as usual.

Downloaded From TheatreSystem-Manual.com Manuals

Problem (USB)	Solution
The contents of the USB flash drive cannot be read.	– The USB flash drive format is not compatible with this unit. – Drive is formatted with a different file system which is not supported by this unit (e.g. NTFS).
Slow operation of the USB flash drive.	– Large file size or high memory USB flash drive takes longer time to read and display on the TV.

Downloaded From TheatreSystem-Manual.com Manuals

Frequently Asked Questions (USB)

Why does it take so long to display the contents on my USB device?

– This could be due to the large numbers of files (>500 files/folders) or size of the files (>1MB).
– There could be other non-supported files in the device that this unit is trying to read/display.

What if un-supported devices (e.g. USB mouse, keyboards) are plugged into this unit?

The device may cause this unit to be unstable. Remove the unsupported device and unplug the mains cord. Wait for a few minutes before reconnecting the mains cord and power on this unit again.

What happens when I plug in a USB HDD?

HDD is not supported as the large storage capacity makes navigation very difficult. Transfer the music files (mp3) and photos (jpg) into a flash drive.

Why does this unit fail to detect my USB portable music player?

The portable music player may require propriety software that is bundled with our system in order to access the contents (eg. playlist). MTP class not supported, only can support mass storage class devices.

What types of file does this unit support?

We support only FAT16 and FAT32, not NTFS.

Why does the file name appear to be different from what was displayed on my computer (e.g. from 'Good Bye. jpg' to 'Good_B~1.jpg')?

– The length of the file name is restricted by the file system of the device (FAT16), which only supports eight (8) characters.
– The computer may be able to display the full file name as the operating system can convert the file system.

Is simultaneous USB and Disc playback possible?

This is not possible due to memory limitation. In addition, a different user interface will be needed in order to function and in order to be simple enough to use.

Why can't I rotate the pictures in my device?

In order to rotate the pictures in the USB device, the picture must contain EXIF information, stored by most digital cameras. This EXIF information may have been removed when you edit or copy the picture from other devices using editing programmes.

Why can't this unit play some of my music files, photos or movies?

The music files may not be playable because of different formats and encoding bit-rates. Similarly, the photos may be of low resolution or too high resolution for this unit to support.

Downloaded From TheatreSystem-Manual.com Manuals

Specifications

English

AMPLIFIER

Total output power –
Home Theatre mode: 300 W
Frequency Response: 180 Hz – 18 kHz / ±3 dB
Signal-to-Noise Ratio: > 60 dB (A-weighted)
Input Sensitivity

- AUX In :	500 mV
- TV In:	250 mV
- MP3 Line-In:	500 mV

RADIO

Tuning Range:	FM 87.5–108 MHz (50/100kHz) AM 531–1602 kHz (9kHz) AM 530–1700 kHz (10kHz)
26 dB Quieting Sensitivity:	FM 22 dBf, AM 5000µV/m
IF Rejection Ratio:	FM 60 dB, AM 24 dB
Signal-to-Noise Ratio:	FM 50 dB, AM 30 dB
AM Suppression Ratio:	FM 30 dB
Harmonic Distortion:	FM Mono 3% FM Stereo 3% AM 5%
Frequency Response	FM 180 Hz–9 kHz / ±6 dB
Stereo Separation	FM 26 dB (1 kHz)
Stereo Threshold	FM 23.5 dB

DISC

Laser Type	Semiconductor
Disc Diametre	12cm / 8cm
Video Decoding	MPEG-1 / MPEG-2 / / DivX 3/4/5/6, Ultra
Video DAC	12 Bits
Signal System	PAL / NTSC
Video Format	4:3 / 16:9
Video S/N	56 dB (minimum)
Composite Video Output	1.0 Vp-p, 75Ω
Audio DAC	24 Bits / 96 kHz
Frequency Response	4 Hz–20 kHz (44.1 kHz) 4 Hz–22 kHz (48 kHz) 4 Hz–44 kHz (96 kHz)
PCM	IEC 60958
Dolby Digital	IEC 60958, IEC 61937
DTS	IEC 60958, IEC 61937

MAIN UNIT

Power Supply Rating:	110-127 V / 220-240 V~ 50-60 Hz switchable
Power Consumption:	60 W
Dimensions:	360 x 48 x 332 (mm) (w x h x d)
Weight:	2.82 kg

FRONT AND REAR SPEAKERS

System:	Full range satellite
Impedance:	4 Ω
Speaker drivers:	3" full range speaker
Frequency response:	150 Hz – 20 kHz
Dimensions:	95.5 x 198 x 75 (mm) (w x h x d)
Weight:	0.53 kg/each

CENTRE SPEAKER

System:	Full range satellite
Impedance:	8 Ω
Speaker drivers:	3" full range speaker
Frequency response:	150 Hz – 20 kHz
Dimensions:	240 x 99.5 x 64 (mm) (w x h x d)
Weight:	0.85 kg

SUBWOOFER

Impedance:	8 Ω
Speaker drivers:	165 mm (6.5") woofer
Frequency response:	40 Hz – 150 Hz
Dimensions:	131.2 x 315.5 x 386 (mm) (w x h x d)
Weight:	3.93 kg

Specifications subject to change without prior notice.

1_hts3152_98_eng2.indd 49 2007-04-26 7:15:02 PM
Downloaded From TheatreSystem-Manual.com Manuals

Glossary

Analogue audio: Sound that has not been turned into numbers. Analogue sound is available with you use the AUDIO LEFT/ RIGHT. These red and white sockets send audio through two channels, the left and right.

Aspect ratio: Aspect ratio refers to the length to height ratio of TV screens. The ratio of a standard TV is 4:3, while the ratio of a high-definition or wide TV is 16:9. The letter box allows you to enjoy a picture with a wider perspective on a standard 4:3 screen.

AUDIO OUT sockets: Red and white sockets on the back of the unit that send audio to another system (TV, Stereo, etc)..

Bit Rate: The amount of data used to hold a given length of music; measured in kilobits per second, or kbps. Or, the speed at which you record. Generally, the higher the bit rate, or the higher the recording speed, the better the sound quality. However, higher bit rates use more space on a disc.

Chapter: Sections of a picture or a music piece on a DVD that are smaller than titles. A title is composed of several chapters. Each chapter is assigned a chapter number enabling you to locate the chapter you want.

Composite video (CVBS): A single video signal commonly used in most consumer video products.

Disc menu: A screen display prepared for allowing a selection of images, sounds, subtitles, multi-angles, etc., recorded on a DVD.

DivX: The DivX code is a patent-pending, MPEG-4 based video compression technology, developed by DivX Networks, Inc., that can shrink digital video to sizes small enough to be transported over the internet, while maintaining high visual quality.

Dolby Digital: A surround sound system developed by Dolby Laboratories containing up to six channels of digital audio (front left and right, surround left and right, centre and subwoofer).

Dolby Surround Pro Logic II: It is an improved matrix decoding technology that provides better spatiality and directionality on Dolby Surround programme material, provides a convincing three dimensional sound field on conventional stereo music recordings and is ideally suited to bring the surround experience to automotive sound. While conventional surround programming is fully compatible with Dolby Surround Pro Logic II decoders, soundtracks will be able to be encoded specifically to take full advantage of Pro Logic II playback, including separate left and right surround channels. (Such material is also compatible with conventional Pro Logic decoders).

DTS: Digital Theatre Systems. This is a surround sound system, but it is different from the Dolby Digital. The formats were developed by different companies.

JPEG: A very common digital still picture format. A still-picture data compression system proposed by the Joint Photographic Expert Group, which features small decrease in image quality in spite of its high compression ratio. Files are recognised by their file extension 'JPG or JPEG'.

MP3: A file format with a sound data compression system. 'MP3' is the abbreviation of Motion Picture Experts Group 1 (or MPEG-1) Audio Layer3. By using the MP3 format, one CD-R or CD-RW can contain about 10 times more data than a regular CD.

Downloaded From TheatreSystem-Manual.com Manuals

MPEG: Motion Picture Experts Group. A collection of compression systems for digital audio and video.

Multi-channel: DVDs are formatted to have each sound track constitute one sound field. Multi-channel refers to a structure of sound tracks having three or more channels.

PBC: Playback Control. A system of navigating a Video CD/Super VCD through on-screen menus recorded onto the disc. You can enjoy interactive playback and searching.

Progressive Scan: The progressive scan displays twice the number of frames per second than in an ordinary TV system. It offers higher picture resolution and quality.

Region code: A system allowing discs to be played only in the region designated. This unit will only play discs that have compatible region codes. You can find the region code of your unit by looking at the product label. Some discs are compatible with more than one region (or ALL regions).

Surround: A system for creating realistic three dimensional sound fields full of realism by arranging multiple speakers around the listener.

Title: The longest section of a movie or music feature on DVD. Each title is assigned a title number, enabling you to locate the title you want.

WMA: Windows Media™ Audio. Refers to an audio compression technology developed by Microsoft Corporation. WMA data can be encoded by using Windows Media Player version 9 or Windows Media Player for Windows XP. Files are recognised by their file extension 'WMA'.

Downloaded From TheatreSystem-Manual.com Manuals